


**LASER 2000**

Instructions for RF Drivers

Brimrose offers a large variety of RF Drivers compatible with our Acousto-Optic components. The following instructions will help you choose and pick the proper driver for your application. If there are any questions please contact Brimrose Corporation of America.

Fixed Frequency Driver Guide



D-A-CH

Laser 2000 GmbH
82234 Wessling
Tel. +49 8153 405-0
info@laser2000.de
www.laser2000.de

FRANCE – Telecom

Laser 2000 SAS
78860 St-N. I. Bretèche
Tel. +33 1 30 80 00 60
info@laser2000.fr
www.laser2000.fr

FRANCE – Photonic

Laser 2000 SAS
FR-33600 Pessac
Tel. +33 5 57 10 92 80
info@laser2000.fr
www.laser2000.fr

IBERIA

Laser 2000 SAS
28034 Madrid
Tel. +34 650 529 806
info@laser2000.es
www.laser2000.es

NORDICS

Laser 2000 GmbH
112 51 Stockholm
Tel. +46 8 555 36 235
info@laser2000.se
www.laser2000.se