

**LASER 2000**

CTC

Connector, Termini & Contact Polisher

Benchtop Polisher for Small & Medium Volume Fiber Terminations

Developed for small and medium production batch applications, **CTC** Portable Fiber Optic Connector Polishers provides the performance required by installation professionals on fiber optic connectors, termini and contacts.

CTC utilizes a unique latched fiber positioning system which is height adjustable for differing ferrule lengths, along with an automatic oscillating polishing movement. A timer control allows for pre-defined polishing sequences to be achieved by the operator.

CTC uses 2" lapping and polishing films, providing maximum value and a lower 'price per connector'. Consumables and films are in stock at ULTRA TEC at all times.

The standard package for the unit incorporates the following items:

- Polisher
- 5 Resilient Polishing Platens
- 12V Converter



D-A-CH

Laser 2000 GmbH
82234 Wessling
Tel. +49 8153 405-0
info@laser2000.de
www.laser2000.de

FRANCE – Telecom

Laser 2000 SAS
78860 St-N. I. Bretèche
Tel. +33 1 30 80 00 60
info@laser2000.fr
www.laser2000.fr

FRANCE – Photonic

Laser 2000 SAS
33600 Pessac
Tel. +33 5 57 10 92 80
info@laser2000.fr
www.laser2000.fr

IBERIA

Laser 2000 SAS
28034 Madrid
Tel. +34 650 529 806
info@laser2000.es
www.laser2000.es

NORDICS

Laser 2000 GmbH
112 51 Stockholm
Tel. +46 8 555 36 235
info@laser2000.se
www.laser2000.se

Product Specifications

System Part #	8802.4 – CTC Four Position Polisher
Lap Diameter	2 inches (50mm)
Weight	2.27 kg (5 lbs)
Power Supply	12V convertor
Timer	10 – 120 Seconds

System Accessories

4093.1	Resilient Surface Polishing platen
4026.1	220V AC Adapter

Connector holders

4044.12	ST
4005.12	SC
4011.12	Ferrule (2.5mm)
4011.22	Ferrule (1.25mm)
4011.32	Ferrule (2.0mm)
4013.12	MU
4014.12	FC
4015.12	LC

Lapping & Polishing Films

2200.2	MULTIMODE Polishing Kit
2200.3	SINGLEMODE Polishing Kit

D-A-CH

Laser 2000 GmbH
82234 Wessling
Tel. +49 8153 405-0
info@laser2000.de
www.laser2000.de

FRANCE – Telecom

Laser 2000 SAS
78860 St-N. I. Bretèche
Tel. +33 1 30 80 00 60
info@laser2000.fr
www.laser2000.fr

FRANCE – Photonic

Laser 2000 SAS
33600 Pessac
Tel. +33 5 57 10 92 80
info@laser2000.fr
www.laser2000.fr

IBERIA

Laser 2000 SAS
28034 Madrid
Tel. +34 650 529 806
info@laser2000.es
www.laser2000.es

NORDICS

Laser 2000 GmbH
112 51 Stockholm
Tel. +46 8 555 36 235
info@laser2000.se
www.laser2000.se